



Standard Practice for Open-Path Fourier Transform Infrared (OP/FT-IR) Monitoring of Gases and Vapors in Air¹

This standard is issued under the fixed designation E1982; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope

1.1 This practice covers procedures for using active open-path Fourier transform infrared (OP/FT-IR) monitors to measure the concentrations of gases and vapors in air. Procedures for choosing the instrumental parameters, initially operating the instrument, addressing logistical concerns, making ancillary measurements, selecting the monitoring path, acquiring data, analyzing the data, and performing quality control on the data are given. Because the logistics and data quality objectives of each OP/FT-IR monitoring program will be unique, standardized procedures for measuring the concentrations of specific gases are not explicitly set forth in this practice. Instead, general procedures that are applicable to all IR-active gases and vapors are described. These procedures can be used to develop standard operating procedures for specific OP/FT-IR monitoring applications.

1.2 The values stated in SI units are to be regarded as standard. No other units of measurement are included in this standard.

1.3 *This practice does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this practice to establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to use.*

2. Referenced Documents

2.1 ASTM Standards:²

E131 Terminology Relating to Molecular Spectroscopy

E168 Practices for General Techniques of Infrared Quantitative Analysis (Withdrawn 2015)³

¹ This practice is under the jurisdiction of ASTM Committee E13 on Molecular Spectroscopy and Separation Science and is the direct responsibility of Subcommittee E13.03 on Infrared and Near Infrared Spectroscopy.

Current edition approved Jan. 1, 2013. Published January 2013. Originally approved in 1998. Last previous edition approved in 2007 as E1982 – 98 (2007). DOI: 10.1520/E1982-98R13.

² For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

³ The last approved version of this historical standard is referenced on www.astm.org.

E1421 Practice for Describing and Measuring Performance of Fourier Transform Mid-Infrared (FT-MIR) Spectrometers: Level Zero and Level One Tests

E1655 Practices for Infrared Multivariate Quantitative Analysis

E1685 Practice for Measuring the Change in Length of Fasteners Using the Ultrasonic Pulse-Echo Technique

2.2 Other Documents:

FT-IR Open-Path Monitoring Guidance Document⁴

Compendium Method TO-16 Long-Path Open-Path Fourier Transform Infrared Monitoring of Atmospheric Gases⁵

3. Terminology

3.1 For definitions of terms used in this practice relating to general molecular spectroscopy, refer to Terminology E131.

3.2 For definitions of terms used in this practice relating to OP/FT-IR monitoring, refer to Guide E1685.

3.3 For definitions of general terms relating to optical remote sensing, refer to the FT-IR Open Path Monitoring Guidance Document.

4. Significance and Use

4.1 An OP/FT-IR monitor can, in principle, measure the concentrations of all IR-active gases and vapors in the atmosphere. Detailed descriptions of OP/FT-IR systems and the fundamental aspects of their operation are given in Guide E1685 and the FT-IR Open-Path Monitoring Guidance Document. A method for processing OP/FT-IR data to obtain the concentrations of gases over a long, open path is given in Compendium Method TO-16. Applications of OP/FT-IR systems include monitoring for gases and vapors in ambient air, along the perimeter of an industrial facility, at hazardous waste sites and landfills, in response to accidental chemical spills or releases, and in workplace environments.

⁴ EPA/600/R-96/040, National Technical Information Service Technology Administration, U.S. Department of Commerce, Springfield, VA 22161, NTIS Order No. PB96-1704771NZ.

⁵ *Compendium of Methods for the Determination of Toxic Organic Compounds in Ambient Air*, 2nd Ed., EPA/625/R-96/010b, Center for Environmental Research Info., Office of Research & Development, U.S. Environmental Protection Agency, Cincinnati, OH 45268, Jan. 1997.